


SERVICE MANUAL

SEEBURG

STEREO CONSOLETTA

TYPE

SC1



MANUAL NO. 55065

Printed In U.S.A.

THE SEEBURG SALES CORPORATION
Chicago 22 Illinois

STEREO CONSOLETTA, Type SC1

PHONOGRAPH AUDIO POWER CONSIDERATION

In locations where the Stereo Consolette has been installed close to the phonograph, adjustments should be made at the amplifier to reduce phonograph speaker power. Excessive output from the phonograph speakers will override and negate the sound emanating from the stereo speakers in the Consolette. As low as a 2-

watt phonograph speaker setting may be required, however, the total amplifier load should not be less than 6 watts.

Refer to the LPC Installation Manual, Part No. 487390 for typical system installation using Stereo Consolettes. Note that total amplifier loading must not exceed 25 watts per channel.

INSTALLATION OF TERMINAL BOARD COVER, CABLE CHANNEL & BOTTOM HOLE COVER




Figure 19.

The above illustration shows the placement and installation of the Terminal Board Cover, Cable Channel and Bottom Hole Cover as required in the Stereo Consolette, Type SC1, and detailed in the Manual Section titled "Wiring the Consolette", paragraphs 1 through 5.

REMOVAL & INSTALLATION OF APU10

TO REMOVE APU10

1. Rotate Contact Wiper Arm on Motor Assembly to position shown in Fig. 1.
2. Disconnect the 12 contact plug.
3. Remove mounting screws. (Fig. 4).
4. Pull unit forward until free of locating pins on SC1 backplate, lift on right side turning right side outward while lifting.
CAUTION do not touch Coin Switch!




Fig. 1.

TO INSTALL APU10

1. Rotate Contact Wiper Arm to position shown in Fig. 1.
2. Pull Return Lever on Motor Assembly away from SC1 Back Plate. (Fig. 3).
3. Reverse step 4 removal procedure. Be sure Pawl Pin on Cancel Slide is between Return Lever and SC1 Back Plate. (Fig. 3).
4. Start the mounting screws. Make sure to use flatwashers if they were used previously.
5. Rotate Contact Wiper Arm to Credit Position. (Fig. 2).
6. To get proper Cancel Slide "end play" clearance of $\frac{1}{32} \pm \frac{1}{64}$ slide APU10 backward or forward. This is IMPORTANT for unit to subtract properly. (Fig. 4). SEE NOTE BELOW.
7. Tighten screws, recheck "end play", and insert plug.




Fig. 2.




Fig. 3.





Fig. 4.



NOTE: TO AVOID BINDS, CHECK ADJUSTMENT AND ASSURE CORRECT SUBTRACT FUNCTION. ESTABLISH THIRTEEN (13) CREDITS AND, WITH ALBUM RELAY IN ENERGIZED POSITION, CHECK FOR CLEARANCE BETWEEN CANCEL PAWL AND GEAR SEGMENT AT POINT "X"; SEE ILLUSTRATION ABOVE.