



Pioneer Jukebox, Y-cable Installation

The purpose of the Y-cables are to join the three separate left and right audio inputs to a single player input



1) Start with the right channel, take 1st Y-cable, connect one male plug to Player 1, the other to Player 2.

2) Take 2nd Y-cable, connect one male plug to Player 3, the other to female end of 1st Y-cable. Connect the red male plug from player to the female end of 2nd Y-cable.



3) Do left channel using same steps as right channel.

4) White plug from player to female end of 2nd Y-cable.